

FCC ID: 2APR4-BEE

This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20 cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Thank you for choosing the **OneNet™** Node

← Set-up in 1 step



ⓘ You need a working **OneNet™** router to use the **OneNet™** mesh node.

Need help setting up your **OneNet™** router? Please scan this QR code:

Or visit: www.inverto.tv/support




www.inverto.tv




OneNet™
MESH WIFI Node
Set-up Guide

V050421


Set-up Guide




After you install the OneNet™ Wi-Fi router, you will only need to **plug in the OneNet™ nodes** and the mesh system will be created **automatically**.



- After the mesh system is created successfully, the OneNet™ node's indicator light will turn green and stop blinking.



- If the OneNet™ node's indicator light blinks, it means that the signal is weak. Please move the OneNet™ node closer to the other nodes (Nodes or Routers) in the mesh network.



- If the OneNet™ node fails to connect to the mesh system or there is no internet, the indicator light will be red and steady. Please check the network status of the OneNet™ host router or shorten the distance between the OneNet™ node and the other OneNet™ nodes (Nodes or Routers)

Download the OneNet™ app

Control your mesh network from anywhere, anytime

Android users

Please download the application from:

www.inverto.tv/support or scan the **QR code** below.

iOS users

The application will be available soon.



🔍 Need help?

⚠️ If you want to connect the OneNet™ node to a different OneNet™ router, from a separate package, please follow the instructions from the link below:

www.inverto.tv/support